

# MODEL 300

Operating Instructions  
764-25 9807



## FEATURES

- General photographic timing
- Two switchable outlets
  - Safelight outlet
  - Enlarger or Printer outlet
- Split-second accuracy
- “Seconds” hand rotates one revolution/min
- “Minutes” hand rotates one revolution/hour
- Power switch starts the timing cycle
- End of cycle buzzer
  - Adjustable from 0 dB to 80 dB
- Luminous Dial
  - Glows 20-30 minutes
  - “Recharge” with incandescent or fluorescent light

## Example:

### *Automatic Enlarger Timing*

1. Set ON-OFF switch to “off”.
2. Plug enlarger into outlet marked ENLARGER.
3. Set TIME-FOCUS switch to “focus”.
4. Turn ON-OFF switch to “on” and focus enlarger. Then turn to “off” again.
5. Set timer hands clockwise to desired setting. Also, set TIME-FOCUS switch to “time”.
6. Turn ON-OFF switch to “on”.
7. Result: Timer will automatically turn enlarger off after selected time interval.

## Safelight Operation

1. Plug safelight into outlet marked SAFELIGHT.
2. When TIME-FOCUS switch is set to “focus” and enlarger is turned on, safelight will be turned off automatically, eliminating any extraneous light.
3. With TIME-FOCUS switch set to “time” and the enlarger if on, safelight is automatically turned off, eliminating shadows when a dodging operation is necessary.
4. When timer hands reach zero automatically turning enlarger off, safelight will automatically turn on providing light for your next operation.
5. You may switch another appliance on after a timed interval by connecting it to the safelight outlet.

## PRECAUTIONS

- To prevent fire or electrical shock, do not expose to rain or moisture.
- No user serviceable parts inside – do not open.
- Refer servicing to qualified personnel.
- Observe AC line voltage, frequency and load ratings on nameplate.

