

Code Notches for KODAK Sheet Films



Kodak sheet films have a notch or a group of notches on one edge of each sheet. These notches serve two purposes: They indicate the film type and help you to identify the emulsion side quickly. When the notch is at the top right edge of the sheet, the emulsion side faces you.

KODAK Color Negative and Print Films for Process C-41

PORTRA 160NC



PORTRA 160VC



PORTRA 400NC



PORTRA 100T



Commercial Internegative*



VERICOLOR Print



KODAK Color Transparency Films for Process E-6

EKTACHROME 64
Professional / EPR



EKTACHROME 100
Professional / EPN



EKTACHROME 100 Plus
Professional / EPP



EKTACHROME 64T
Professional / EPY



EKTACHROME E100G



EKTACHROME E100S*



EKTACHROME E100SW*



EKTACHROME E100VS



EKTACHROME Duplicating
EDUPE



EKTACHROME Electronic
Output 100



EKTACHROME Electronic
Output 64T



*To be discontinued when stock runs out.

Code Notches for KODAK Sheet Films

KODAK Black-and-White Films

Contrast Process Ortho /
4154*



Fine Grain Positive 7302*



(Universal Notch)

KODALITH Ortho 2556,
Type 3



(No Notch)

Professional B/W
Duplicating, SO-132*



(Universal Notch)

Technical Pan / TP



(Universal Notch)

PLUS-X Pan Professional /
PXT*



T-MAX 100 / 100TMX



T-MAX 100 Professional /
TMX*



T-MAX 400 / 400TMY



TRI-X 320 / 320TXP



TRI-X Pan Professional /
TXT*



Universal Code Notches

These code notches are for low-volume and special-order (SO) films.

Films for
Black-and-White
Processes



Films for Process E-6



Films for Process C-41



*To be discontinued when stock runs out.



Kodak Professional Division
EASTMAN KODAK COMPANY

Kodak Professional