

Calibration Routines for KODAK PROFESSIONAL SUPRA ENDURA Paper



GENERAL INFORMATION

KODAK PROFESSIONAL SUPRA ENDURA Paper is optimized for both digital and optical printers. Significant testing has been done across a broad range of Kodak Professional and OM digital printers to validate satisfactory digital performance of KODAK PROFESSIONAL SUPRA ENDURA Paper.

Kodak's Printer Calibrations for KODAK PROFESSIONAL SUPRA ENDURA Paper

To achieve optimal quality prints on KODAK PROFESSIONAL SUPRA ENDURA Paper with Kodak digital output devices such as the KODAK PROFESSIONAL Digital Multiprinter or the KODAK PROFESSIONAL LED II Printer, you must install new calibration files.

The latest calibration files for Windows NT and 2000 (V4.3) and Macintosh (V4.3) operating systems are available at www.kodak.com/go/servicesupport. If your

printer does not have the newest calibration files, download and install them at this time. These files currently support: LED and laser printers, including:

- KODAK PROFESSIONAL RR 30 Laser Printer
- KODAK PROFESSIONAL RP 30 and SRP 30 Laser Printers
- KODAK PROFESSIONAL RP 50 LED Printer
- KODAK PROFESSIONAL LED II Printers 20R and 20P
- KODAK PROFESSIONAL LED Digital Color Printers 20R and 20P

CRT printers, including:

- KODAK PROFESSIONAL Digital Multiprinters (KPDM & KPDM II)
- KODAK DIGITAL SCIENCE LF CRT Color Printer
- KODAK 4" CRT Color Printer

Other Equipment Manufacturer's Printer Calibration for KODAK PROFESSIONAL SUPRA ENDURA Paper

The starting-point recommendations listed in the following table have yielded good image quality in prints on KODAK PROFESSIONAL SUPRA ENDURA Paper produced by other equipment manufacturers' digital output devices.

Calibration Routines for KODAK PROFESSIONAL SUPRA ENDURA Paper

Printer	Calibration
Oce LightJet 430 and 5000	<ol style="list-style-type: none"> 1. Go to the Oce FTP Site at www.oce-dgs.com/PrinterSupport/LJ_Customer_Access. 2. Read the "Lightjet Media Read Me" document for information regarding downloading printer aims. 3. Select the link to the Media Targets for your Lightjet printer. 4. Download the appropriate aim files, as directed in the read-me file.
Durst Lambda 130 and 76+	Starting D-max: 2.30R, 2.20G, 2.20B (It is possible to obtain higher D-max in images that do not include text.) Basic Calibration settings: Y=113.60, M=82.20, C=0.00, D=96.20
Durst Epsilon 30	For best results, select HIQ or SIQ mode. Starting D-max: 2.30R, 2.15G, 2.15B Basic Calibration settings: D=0.734, C=0.000, M=0.199, Y=0.353
Durst Theta 76	Starting D-max: 2.25R, 2.20G, 2.15B Basic Calibration settings: D=.0689, C=0.0, M=0.162, Y=0.335
Durst Theta 50/51	Starting D-max: 2.30R, 2.25G, 2.20B Basic Calibration settings: D=91.61, C=0.0, M=105.58, Y=176.74
Durst Zeta	Please contact Bill Conger at Durst Dice America, telephone (585-) 486-0340, extension 5291.
Fuji Frontier	We recommend that you use KODAK PROFESSIONAL SUPRA ENDURA Paper to calibrate the printer channel that you plan to use. If you don't have a recommended channel that you normally use, please start testing with Channel I. <ol style="list-style-type: none"> 1. Load SUPRA ENDURA Paper into the paper magazine that you will use to print. 2. From the Setup and Maintenance menu, select Print Condition Setup and Check. Then select Paper Condition Setup to perform a standard calibration.
Noritsu QSS-2711 and Noritsu MP1600	Setting up a Channel for KODAK PROFESSIONAL SUPRA ENDURA Paper <ol style="list-style-type: none"> 1. Set up a paper channel with SUPRA ENDURA Paper, using the normal Setup procedure. This setup includes MLVA Setup, Uniformity, and Gamma tests. 2. If any color changes are needed, enter them using the Magazine Balance function on the NORITSU MP1600 printer.
Noritsu QSS 31XX, 32XX, 33XX, 34XX, and R2R printers	Contact Noritsu for the software to create a channel for KODAK PROFESSIONAL SUPRA ENDURA Paper.
Polielettronica LASERLAB	<ol style="list-style-type: none"> 1. Set these starting Laser Maximum Density values: Y=198, M=154, C=124. 2. Starting Color Compensation Values Y=0.97, M=0.92, C=1.01. 3. Proceed with the manufacturer's standard paper calibration procedure.
Gretag Netprinter	Basic Data required for calibration are available from Gretag Imaging.
Sienna Mileca HSP	Basic Data required for calibration are available from Sienna Imaging.
ZBE Chromira 30	Select Kodak on the Emulsion menu, and enter: D-max Aim: 2.40R, 2.35G, 2.25B Starting Calibration Values: (C) 0, (M) 12, (Y) -91, (D) 0 Then follow the standard paper calibration procedure.



EASTMAN KODAK COMPANY

Kodak Professional
Imaging Solutions